

1/12

A STATE OF THE STA




2/12




				3 /	/ 1 2	2		
⊢		V	9	IN CASE OF NO ANTENNA TABLE	AN-1	A - 2	TRAMSMIT DATA TO 400 [#2]	6
		,	a		A T	A N T 2	RECEIVE DATA FROM 400 [#1]	@
			a		ANT1	A N + 2	TRAMSMIT DATA TO 400 [#1]	0
ო			٩		ANT1	ANT2	CONNECT RESPONSE TO 400 [#2]	9
Я Э			٩		ANT1	ANT2	CONNECT REQUEST FROM 400 [#2]	©
Щ			a		A F		CONNECT Response To 400 [#1]	(4)
			a		AN-1		CONNECT REQUEST FROM 400 [#1]	©
			q				REFERENCE REFERENCE SIGNAL SIGNAL	©
			a				REFERENCE Signal	Θ
-1	ANTENNA 501	ANTENNA	ANTENNA SWITCH	ANTENNA TABLE	WIRELESS TERMINAL APPARATUS 400 [#1]	WIRELESS TERMINAL APPARATUS 400 [#2]	EXAMPLARY COMMUNICATION	No.


TRANSMISSION RECEPTION




The state of the s


FIG. 5







F I G. 7









9/12







1 1 / 1 2

11

FIG. 12A **START** E1~ POWER SUPPLAY ON E 2 NO HAS REFERENCE SIGNAL RECEIVED ? E 3 YES TRANSMIT CONNECTION REQUEST SIGNAL E 4 NO HAS IT RESPONSED? YES E 5 NO HAS DATA RECEIVED ? YES STORE RECEIVED DATA E6~ EXECUTE DATA PROCESSING

1 2 / 1 2

